

TRANSMISSION REPAIRS

A35

25




Fig. 7

TOMO	5
------	---

TRANSMISSION REPAIRS

A35

27




Fig. 9




Fig. 10




Fig. 11



CYLINDER, PISTON, REED VALVE REPAIRS

A35

37

NOTE:

Replacement of cpl. reed valve is suggested.




Fig. 21

Check conrod bending by help of two calippers (Fig. 22). Check the needle bearing clearance and bearing rolling surface for damage.




Fig. 22



WHEELS AND BRAKES

A35

43

Wheels are cast aluminium alloy type. No special maintenance is required as usual ball bearings greasing and wear checking.

Brakes are drum type (fig. 34) thus there is a periodically need of linings dust (non asbestos) cleaning; cable controls, brake operating cam and brake shoes support pin greasing. Disassembly of brake shoes is easier with pliers - special tool 736.913.





Fig. 34



TOMOS

TOMOS A 35



workshop manual